

- MCB Hardware modifications:
 - Physically remove component F2.
 - Wire (on the bottom of the board) TP6 to TP26.
 - Remove jumper JP2
 - Connect pins 2&6 from J6A to pin 35&37 from J3A (FPGA)
 - Remove standoffs from S-LINK card (they appear to be too long anyway).
 - Protect the exposed PCB lands and support the S-LINK board.